

CONTENT

Chapter 1 Specification	8
1-1 Mainboard Specifications	9
1-1.1 CPU Socket	9
1-1.2 Sysem Chipset Architecture	9
1-1.3 Memory	9
1-1.4 AMI BIOS V2.01A	9
1-1.5 Hardware Monitoring	9
1-1.6 Multi-I/O Function	10
1-1.7 Expansion Slots	10
1-1.8 Accelerated Graphics port (AGP) Interface	10
1-1.9 FORM FACTOR	10
1-1.10 Sound Controller	11
1-1.11 Power Management	11
1-2 Mainboard Layout	12
1-3 Chipset System Block Diagram	13
Chapter 2 Hardware Setup	15
2-1 Pentium 4 CPU Installation with Socket 478	16
2-2 Pentium 4 CPU Fan Installation:	17
2-3 Memory Installation	18
2-3.1 To Install DIMM Module	18
2-3.2 To Remove a DIMM:	18
2-4 AGP 4X (Accelerated Graphics Port) Installation	19
2-5 HDD/FDD Installation	20
2-6 Jumper and Switch Settings	22
2-6.1 Switch 1 CPU Clock Select	23
2-6.2 Factory Test (By JP2)	24
2-6.3 Memory Module Voltage Select (By JP3/JP4)	24

2-6.4 JP13 Memory Stick/Secure Digital Memory Card Reader Select	25
2-6.5 AGP Voltage Select (By JAGP1/JAGP2)	25
2-6.6 JBAT1 Clear CMOS	26
2-7 Other Connectors Configuration	27
2-7.1 On Board FAN Connectors (FAN1,FAN2, FAN3)	27
2-7.2 WOL1 Wake On LAN	28
2-7.3 CD-ROM Audio Connector (CD9/CD10)	29
2-7.4 Thermal Sensor Connector RT2 (Optional)	30
2-7.5 Complex Header NJ1	31
2-7.6 ATX Power Supply Connectors version 2.03 for Pentium 4	33
2-7.7 CMEM1 Memory Stick™/Secure Digital Memory Card Reader Connector	34
2-7.8 Communication And Networking Riser Slot (CNR)	35
2-7.9 Smart Card Reader Connector (SCR1)	36
2-7.10 USB Header (Header USB1)	37
2-7.11 PS/2 Mouse And PS/2 Keyboard	37
2-7.12 Chassis Panel Connector	38
2-8 IRQ Description	39
Chapter 3 Software Setup	41
3-1 Open up the Support CD and choose Drivers and Utilities	42
3-2 Install “Intel Chipset Software Installation Utility”	43
3-3 Install “Intel Application Accelerator”	44
3-4 AC'97 Audio Driver Installation	46
3-5 Install Hardware Monitor Utility	47
3-5.1 Installation	47
3-5.2 Verification	48
Chapter 4 BIOS Setup	50
4-1 About BIOS Setup	51

4-2 To run BIOS Setup	51
4-3 About CMOS	51
4-4 The POST (Power On Self Test)	51
4-5 To upgrade BIOS	52
4-5.1 Before Upgrading BIOS	52
4-5.2 Upgrade Process	52
4-6 BIOS Setup --- CMOS Setup Utility	54
4-6.1 CMOS Setup Utility	54
4-6.2 Standard CMOS Setup	55
4-6.3 Advanced BIOS Features	58
4-6.4 Advanced Chipset Features	62
4-6.5 Power Management Setup	66
4-6.6 PNP / PCI Configuration	70
4-6.7 Integrated Peripherals	72
4-6.8 Hardware Monitor Status Features	76
4-6.9 Frequency/Voltage Control	78
4-6.10 Set Supervisor / User Password	80
4-6.11 Load Optimized Defaults	81
4-6.12 Save & Exit Setup	82
4-6.13 Exit Without Saving	82
Appendices	84
Appendix-1 Identifying Mainboard model Number	85
Appendix-2 Technical Terms	86